

Electrical Step

Telescopic Heavy duty 670mm (model T-670)

(Fitted under the front door)

Model	LHD vehicles right step Auto Cool P/N		RHD vehicles left step Auto Cool P/N	
	(Step+brackets)	(Brackets only)	(Step+brackets)	(Brackets only)
Mercedes Sprinter MWB, LWB	016-0004-51	160-16-051	016-0004-51	160-16-051
Volkswagen Crafter MWB, LWB	016-0004-51	160-16-051	016-0004-51	160-16-051
Renault Master L2, L3, L4 from 2010	016-0004-9	160-16-409		
Opel Movano L2, L3, L4 from 2010	016-0004-9	160-16-409		
Iveco Daily MWB, LWB	016-0004-2	160-99-002		
Ford up 2014	Transit RWD: MWB, LWB, Jumbo	016-0004-42	160-16-442	
	Transit FWD: MWB, LWB	016-0004-42	160-16-442	
Ford V363 from 2014	Transit RWD: LWB, Jumbo	016-3634-3	160-16-343	
	Transit FWD: MWB, LWB	016-3634-3	160-16-343	

LHD vehicles
right step



RHD vehicles
left step

