

Short installation time

**AAD**

## Automatic Axial Door

|                                   | <i>Model</i>               | <i>LHD vehicles</i> | <i>RHD vehicles</i> |
|-----------------------------------|----------------------------|---------------------|---------------------|
|                                   |                            | <i>right door</i>   | <i>left door</i>    |
| <i>Auto Cool P/N</i>              |                            |                     |                     |
| Mercedes                          | Sprinter                   | 014-0002            | 014-0005            |
|                                   | Sprinter up to 2006        | 014-0006-1          |                     |
| Volkswagen                        | Crafter                    | 014-0002            | 014-0005            |
| Iveco                             | Daily up to 2014           | 014-0001            |                     |
|                                   | <b>New</b> Daily from 2014 | 014-1510            |                     |
| Renault                           | Master from 2010           | 014-0008            |                     |
| Opel                              | Movano from 2010           | 014-0008            |                     |
| Ford<br>up to 2014                | Transit                    | 014-0003            |                     |
| <b>New</b> Ford V363<br>from 2014 | Transit RWD: LWB, Jumbo    | 014-3630            |                     |

