

Automatic Sliding Door without Latch beginning

	<i>Model</i>	<i>LHD vehicles right door Auto Cool P/N</i>	<i>RHD vehicles left door</i>
Mercedes <i>New</i> <i>New</i>	Sprinter MWB,LWB	015-0003	015-0003-L
	Vito/Viano LWB Long up to 2014	015-0017	015-0007
	Vito/Viano LWB Extra Long up to 2014	015-1017	015-1007
	Vito/V-Class SWB Long from 2015	015-1517	
	Vito/V-Class LWB Extra Long from 2015	015-1537	
Volkswagen	Crafter MWB,LWB	015-0003	015-0003-L
	Caddy LWB (Window van)	015-0019	015-0019-L
	Caddy SWB	015-1019	015-1019-L
	Transporter T-5 SWB	015-0012	015-0012-L
	Transporter T-5 LWB	015-0004	015-0004-L
	Caravelle LWB	015-0018	
	Caravelle SWB	015-1018	
Fiat	Ducato L1	015-0002SW	015-0002SW-L
	Ducato L2,L3,L4	015-0002	015-0002-L
	Scudo L1	015-0008-1	015-0006
	Scudo L2	015-0008	015-0005
Peugeot	Boxer L1	015-0002SW	015-0002SW-L
	Boxer L2,L3,L4	015-0002	015-0002-L
	Expert L1	015-0008-1	015-0006
	Expert L2	015-0008	015-0005
Citroen	Jumper L1	015-0002SW	015-0002SW-L
	Jumper L2,L3,L4	015-0002	015-0002-L
	Jumpy L1	015-0008-1	015-0006
	Jumpy L2	015-0008	015-0005
Renault	Master L2,L3,L4 from 2010	015-1009	015-1011
	Master L2,L3,L4 up to 2009	015-0009*	015-0011*
	Trafic L1 up to 2014	015-0014	
	Trafic L2 up to 2014	015-0027	
Chevrolet	Savana	015-0026	
Hyundai	i-800	015-0021	015-0022
Toyota	Hiace LWB up to 2008	015-0015	
	Hiace Commuter from 2008	015-0025	015-0025-L

* Additional upper lock mechanism
Continued on the next page

Automatic Sliding Door without Latch prolongation

	<i>Model</i>	<i>LHD vehicles right door Auto Cool P/N</i>	<i>RHD vehicles left door Auto Cool P/N</i>
Opel	Movano L2,L3,L4 from 2010	015-1009	015-1011
	Movano L2,L3,L4 up to 2009	015-0009*	015-0011*
	Vivaro L1 up to 2014	015-0014	
	Vivaro L2 up to 2014	015-0027	
Ford up to 2014	Transit MWB, LWB, Jumbo	015-0001	015-0001-L
	Transit SWB	015-0013	
	Custom L1, L2	015-0028	015-0028-L
Ford V363	Transit LWB, Jumbo	015-3631	015-3631-L
	<i>New</i> Transit MWB	015-3633	in the design stage
Iveco	Daily MWB, LWB up to 2014	015-0016*	
	<i>New</i> Daily MWB, LWB from 2014	015-1516	

* Additional upper lock mechanism

Automatic Sliding Door with Original Door Latch Mechanism

	<i>Model</i>	<i>Door Latch Europe M2 Auto Cool P/N</i>	<i>* Door Latch USA M2 Auto Cool P/N</i>
Mercedes	Sprinter MWB,LWB	015-0003-DL	015-0003-DL
	<i>New</i> Vito/V-Class SWB Long from 2015	015-1517-DL	
	<i>New</i> Vito/V-Class LWB Extra Long from 2015	015-1537-DL	
Volkswagen	Crafter MWB,LWB	015-0003-DL	
Fiat	Ducato L2,L3,L4	015-0002-DL	
Dodge	Ram ProMaster L2,L3,L4		015-0002-DL
Peugeot	Boxer L2,L3,L4	015-0002-DL	
Citroen	Jumper L2,L3,L4	015-0002-DL	
Ford V363	Transit LWB, Jumbo	015-3631-DL	
Ford V363 USA	Transit LWB, Jumbo		015-3632-DL
Renault	<i>New</i> Trafic L1 from 2015	015-1514-DL	in the design stage
Opel	<i>New</i> Vivaro L1 from 2015	015-1514-DL	in the design stage
Ford V408	Connect LWB RHD	015-4081-DL	
	Connect LWB LHD	015-4081-L-DL	

* External emergency handle (option)